

Fly Rail Information

<u>Batten #</u>	<u>Distance from Plaster Line</u>	<u>Current Use</u>
0	0' – 11"	Fire Curtain
1	1' – 7"	Main Valance
2	2' – 3"	Grand Drape
3	2' – 11"	Spare
4	3' – 7"	Spare
5	4' – 3"	Legs (31')
6	4' – 11"	1 st Electric
7	6' – 3"	#1 Shell Ceiling
8	8' – 3"	Spare
9	9' – 7"	Da-Lite Screen (22'6"x30')
10	10' – 3"	Border (9')
11	10' – 11"	Legs (24')
12	12' – 3"	2 nd Electric
13	13' – 7"	Spare
14	14' – 3"	FSB
15	14' – 11"	Spare
16	15' – 7"	Border (9')
17	16' – 3"	Legs (24')
18	18' – 3"	#2 Shell Ceiling
19	19' – 7"	Spare
20	20' – 11"	3 rd Electric
21	21' – 7"	Spare
22	22' – 3"	Spare
23	22' – 11"	Border (4')
24	24' – 3"	Black Scrim (can relocate)
25	24' – 11"	Legs (24')
26	25' – 7"	Border
27	26' – 3"	Black Traveler
28	28' – 3"	Spare
29	29' – 7"	#3 Shell Ceiling
30	30' – 11"	4 th Electric
31	32' – 3"	Border
32	32' – 11"	Legs (24')
33	34' – 3"	Spare
34	34' – 11"	5 th Electric
35	36' – 3"	Spare
36	38' – 3"	Cyclorama (White)
37*	38' – 11"	Spare
38*	39' – 7"	Spare
39*	40' – 3"	Spare
40*	40' – 11"	Spare
41*	42' – 3"	Spare
42*	42' – 11"	Spare
Upstage Wall	44' – 4"	Finished Concrete

* Linesets 37–42 are blocked from use when Orchestra Shell is stored upstage (Shell can be stored SL, in wing space)